

# BLDC PUMP

DC Timer



## Input power range:

Working voltage: 8-30 volt, working current: 0-5 ampere.

## Setting instructions:

There are two buttons and three digital tubes in total:

- Left digital tube indicates cycle days, you can set 1-9 days.
- Center digital tube indicate working times during each loop, you can set 1-9 times during one loop. They will be averaged during one loop.
- Right digital tube indicates working minutes in each time. You can set 1-9 minutes in each time.

Press “Select” button to choose digital tube, press “Setting” button to set exact content 1-9.

**For example, we want the pump work 8 times during 9 days, and working 7 minutes every time. We should follow the instructions below:**

- 1) Press “Select” button once, left digital tube flash, press “Setting” button to “9”
- 2) Press “Select” button twice, center digital tube flash, press “Setting” button to “8”
- 3) Press “Select” button three times, right digital tube flash, press “Setting” button to “7”